

UNCLASSIFIED

AD NUMBER

AD459651

LIMITATION CHANGES

TO:

Approved for public release; distribution is unlimited.

FROM:

Distribution authorized to U.S. Gov't. agencies and their contractors;
Administrative/Operational Use; 31 JAN 1965.
Other requests shall be referred to Defense Advance Research Projects Agency, 675 North Randolph Street, Arlington, VA 22203-2114.

AUTHORITY

MICOM ltr, 31 Aug 1966

THIS PAGE IS UNCLASSIFIED

UNCLASSIFIED

AD. **4 5 9 6 5 1**

DEFENSE DOCUMENTATION CENTER

FOR

SCIENTIFIC AND TECHNICAL INFORMATION

CAMERON STATION ALEXANDRIA, VIRGINIA



UNCLASSIFIED

NOTICE: When government or other drawings, specifications or other data are used for any purpose other than in connection with a definitely related government procurement operation, the U. S. Government thereby incurs no responsibility, nor any obligation whatsoever; and the fact that the Government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data is not to be regarded by implication or otherwise as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to manufacture, use or sell any patented invention that may in any way be related thereto.

- 4 5 9 6 5 1

CATALOGED BY DDC
459651
28 MAR 1965
CATALOGED BY DDC
459651
28 MAR 1965

ARPA ORDER NO. 347
PROJECT CODE NO. 7400

GENERAL MOTORS CORPORATION

TECHNICAL REPORT
ON

THE DIAGNOSTIC APPLICATIONS OF MICROWAVE ABSORPTION AND DISPERSION

Sponsored By
ADVANCED RESEARCH PROJECTS AGENCY

Monitored By
U.S. ARMY MISSILE COMMAND


CONTRACT NO. DA-01-021-AMC-11359(Z)
HYPERVELOCITY RANGE RESEARCH PROGRAM
A PART OF PROJECT "DEFENDER"

GM DEFENSE RESEARCH LABORATORIES

SANTA BARBARA, CALIFORNIA



AEROSPACE OPERATIONS DEPARTMENT



TR65-01D

JANUARY 1965

ARPA ORDER NO. 347

Copy No 173

PROJECT CODE NO. 7400

GENERAL MOTORS CORPORATION

TECHNICAL REPORT
ON

THE DIAGNOSTIC APPLICATIONS OF MICROWAVE ABSORPTION AND DISPERSION

I. P. FRENCH

THIS RESEARCH WAS SUPPORTED BY THE
ADVANCED RESEARCH PROJECTS AGENCY
AND WAS MONITORED BY THE
U.S. ARMY MISSILE COMMAND
REDSTONE ARSENAL, ALABAMA

GM DEFENSE RESEARCH LABORATORIES

SANTA BARBARA, CALIFORNIA



AEROSPACE OPERATIONS DEPARTMENT

CONTRACT NO. DA-01-021-AMC-11359(Z)
HYPERVELOCITY RANGE RESEARCH PROGRAM
A PART OF PROJECT "DEFENDER"

TR65-01D

DDC AVAILABILITY NOTICE

Qualified requesters may obtain
copies of this report from DDC

JANUARY 1965

TR65-01D

FOREWORD

This report is one of a series of related papers covering various aspects of a broad program to investigate the flow-field variables associated with hypersonic-velocity projectiles in free flight under controlled environmental conditions. The experimental research is being conducted in the Flight Physics Range of GM Defense Research Laboratories, General Motors Corporation, and is supported by the Advanced Research Projects Agency under Contract No. DA-01-021-AMC-11359(Z). It is intended that this series of reports, when completed, will provide a background of knowledge of the phenomena involved in the basic study and thus aid in a better understanding of the data obtained in the investigation.

The present report is one of a group of three related reports within the above series, all with the same author and treating various aspects of the same subject. The two other reports in this group are:

TR65-01A, "A Review of Microwave Absorption and Dispersion of Air Constituents," and

TR65-01C, "The Microwave Absorption and Dispersion of Heated Air."

The work described in this group of reports was supported partly under the basic contract but includes work supported by GM DRL with in-house funding.

TR65-01D

ABSTRACT

The possibility of measuring species concentration in high-temperature air by microwave spectroscopy is considered. The species selected for consideration are molecular oxygen, which has transitions in the region from 52 to 68 Gc, and nitric oxide with transitions around 150 Gc. The feasibility appears marginal, but this evaluation is based on many approximations and assumptions and further work is required for definitive conclusions.

TR65-01D

CONTENTS

<u>Section</u>		<u>Page</u>
	FOREWORD	ii
	ABSTRACT	iii
I	INTRODUCTION	1
II	THE FABRY-PEROT CAVITY	3
III	USE OF A FABRY-PEROT CAVITY TO MEASURE SPECIES CONCENTRATIONS IN HEATED AIR	5
IV	ABSORPTION AND PHASE SHIFT CAUSED BY FREE ELECTRONS	10
V	CONCLUSIONS AND RECOMMENDATIONS	12
VI	REFERENCES	14

ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>	<u>Page</u>
1	Effect of 60.433 Gc Oxygen Line on the Q of a Fabry-Perot Cavity	7
2	Effect of 150.1763 Gc Nitric Oxide Line on the Q of a Fabry-Perot Cavity	9

TR65-01D

1. INTRODUCTION

The current interest in hypervelocity flight has stimulated a great deal of investigation on the dissociated and ionized plasma sheath and wake around a hypervelocity vehicle. In particular it is very desirable to be able to predict the interaction of electromagnetic waves with this ionized environment. This cannot be done unless the magnitude of electron density, which is closely related to the concentrations of the other constituents in heated air, is known. In addition, the collision frequency of electrons with other particles and the spatial variation of all the constituents is required. Measurements on full-scale hypervelocity vehicles are expensive and difficult, so laboratory facilities for simulating various aspects of hypervelocity flight have been used quite extensively in recent years. One type of facility is the hypervelocity range,^{(1)*} where small models are fired at high velocity into a controlled environment and measurements on the flow field and wake are made. Another very useful tool for studying the chemical kinetics of reactions is the shock tube,⁽²⁾ convenient because aerodynamic considerations are largely unimportant in this essentially one-dimensional flow.

Among the instruments used for measuring electron density in these facilities are electromagnetic probes, using either optical⁽³⁾ or microwave frequencies.⁽⁴⁾ These instruments measure the effective refractive index of the heated, ionized gas as it goes by. The electron density is then deduced from the refractive index. However, the atoms and molecules (which may be neutral) also have an effective index of refraction different from unity. The two effects have very different dispersive behavior, so that it is possible in principle to separate out the two effects by using different frequencies. In fact, it appears possible to measure both the electron density and the concentration of some particular species in the flow by this method.

* References are listed at the end of this report.

TR65-01D

It would be most desirable to measure the concentrations of some species in the far wake, because there are a number of predictions (for example, References 5 and 6) of what the magnitudes ought to be. These predictions could be compared against experiment to deduce more accurate values of the rate constants for the various chemical reactions.

Of particular interest is the feasibility of using a microwave Fabry-Perot cavity^(7,8) to measure the concentration of some species (such as molecular oxygen) in the wake of hypervelocity projectiles in a free-flight range. It appears possible to single out one of the many species in the flow by using a probing frequency in the vicinity of a natural resonance frequency of the species under investigation. It is well known⁽⁹⁾ that the refractive index (assumed complex) of a gas is highly dispersive around a resonance, so that hopefully the effects of the other species in the flow would be negligible in comparison.

The complex dielectric at $1,000^{\circ}\text{K}$ was examined in References 10 and 11, where the contribution of molecular oxygen transitions in the frequency range from 52 to 58 Gc was discussed in detail. Also considered was the band of nitric oxide lines around 150 Gc. Nitric oxide was considered because of its importance in high-temperature chemical reactions in air. The results contained in References 10 and 11 will now be used to determine the feasibility of using the absorption and dispersion properties of heated air as a diagnostic technique.

TR65-01D

II. THE FABRY-PEROT CAVITY

Rotational molecular transitions, which give rise to microwave and far-infrared spectra of gases, are generally very weak. Long path lengths of the gas must be used to increase sensitivities. Another way of increasing sensitivity is by increasing the number of times the microwave energy passes through the gas. This is done by using a microwave resonant cavity. The performance of a cavity is closely related to its "Q" value, which is given by⁽¹²⁾

$$Q = f / \Delta f \quad (1)$$

where f is the operating frequency and Δf is the linewidth of the resonance at the half-power points.

A high Q is required for the greatest sensitivity. It appears that the highest Q 's are attainable with a Fabry-Perot cavity. These instruments have been developed within the last few years for millimeter wavelengths by Culshaw^(13, 14) and have been applied to millimeter wave absorption spectrometry by a group at the National Bureau of Standards.^(15, 16) Currently the Fabry-Perot cavity is being applied to plasma diagnostics^(7, 8) at GM Defense Research Laboratories.

The Q of a Fabry-Perot cavity is given by the well-known expression⁽¹⁵⁾

$$Q = \frac{k L}{A} = \frac{2 \pi L}{\lambda A} \quad (2)$$

where k is the wave number
 L is the plate separation
 and A are the cavity losses.

For an empty cavity with diffraction losses small compared to reflection losses, $A = 1 - |\Gamma|^2$, where Γ is the reflection coefficient of the reflectors. Q 's of about 300,000 have been achieved recently with 10-inch 70-Gc cavities operating in a mode which is close to confocal.⁽⁸⁾

TR65-01D

By using a high Q cavity, very long effective path lengths (the equivalent absorption path length in free space) can be achieved.

L_{eff} is given by⁽¹²⁾

$$L_{\text{eff}} = \frac{Q \lambda}{2\pi} \quad (3)$$

Consequently

$$\frac{L_{\text{eff}}}{L} = \frac{1}{A}$$

Aluminum reflection losses can be as low as 10^{-3} , giving an "improvement factor" (L_{eff}/L) of 10^3 . With such a factor, Gallagher's 7-ft absorption cell⁽¹⁷⁾ is equivalent to a cavity 2.13 cm long. Alternately, a two-meter cavity would have increased the sensitivity by a factor of almost one hundred. The 500-ft-long cell used at the University of Texas⁽¹⁸⁾ is equivalent to a cavity 15.2 cm long. Lichtenstein^(19, 20) et al have recognized that a Fabry-Perot cavity can produce this increase in sensitivity, and have measured H_2S lines at 168 Gc and at 214 Gc with a 4-inch-long cavity whose Q was 56,000. They allowed some diffraction losses to discriminate against higher-order modes, and found that lines with absorptions as low as $3 \times 10^{-5} \text{ cm}^{-1}$ were measurable. A longer cavity ($L \approx 200 \text{ cm}$) with a Q of greater than about 10^6 would allow one to measure lines with absorptions lower than 10^{-6} cm^{-1} .

TR65-01D

III. USE OF A FABRY-PEROT CAVITY TO MEASURE SPECIES CONCENTRATION IN HEATED AIR

In many reentry physics experiments it would be very helpful to be able to measure the concentration of various species in shock-heated gases. Our particular interest is the Flight Physics Range at GM Defense Research Laboratories.⁽⁴⁾ In this facility 1/2" or 7/8" models are fired at high velocity (~ 20,000 feet per sec) into air at low pressure (~ 10 mm Hg) to simulate certain aspects of hypervelocity flight. A plasma sheath and ionized wake are formed around the model and various microwave and radiation measurements are made to deduce the ionization and chemical history of the wake.

It appears that by using microwave absorption spectrometry with a high-Q Fabry-Perot cavity it may be possible to follow the concentration of some air species. The oxygen molecule with absorption resonances at about 60 Gc and with a single line at 118.75 Gc seems a promising candidate, and is of particular importance since generally molecular oxygen starts to reappear when the electrons disappear. Another interesting candidate is nitric oxide, whose concentration generally follows that of the electron density. As noted in previous reports^(10, 11) both of these species have resonances in the millimeter-wavelength part of the spectrum and might therefore be studied with Fabry-Perot cavities.

The effect of the gas in the cavity is twofold. In the first place the gas absorption will increase cavity losses and reduce the Q . In the second place the change in the refractive index as one goes through a resonance causes a shift in the cavity resonance frequency. Both of these effects might be measured by exciting the cavity with a swept-frequency klystron. For the very high Q 's under consideration (~ 10^6), the cavity linewidths (~ 60 kc) will always be much narrower than the linewidth of the resonance it is desired to measure. The cavity resonance can then be used as a very fine probe to sweep across the line.

TR65-01D

Let us consider the type of cavity which would be necessary to measure the 60.433 Gc oxygen line with a peak attenuation of 2 db/km or $\alpha_{\omega} = 0.23 \times 10^{-5} \text{ cm}^{-1}$. Let the cavity losses be taken as 10^{-3} , corresponding to aluminum at this frequency. The increase in Q with cavity length is linear, as shown in Figure 1 (curve a). Diffraction losses are ignored. The change in Q of a cavity resonant at 60.433 Gc when room-temperature air is introduced into it is shown by curve b. The decrease in Q is 13% for a 40-cm cavity and 25% for a 140-cm cavity. When a 4-cm-diameter wake with no oxygen molecules is introduced, however, the resulting change is very small and probably not measurable. The effect of the real part of the dielectric coefficient of air is to change the cavity resonant frequency. This frequency change, Δf , is given by⁽⁷⁾

$$\frac{\Delta f}{f} = \frac{1}{2} \frac{d}{L} \Delta K_r \quad (4)$$

where f is the operating frequency, d the wake thickness, and L the cavity length. ΔK_r is the contribution of the oxygen molecules to the real part of the dielectric coefficient. Figure 5a of Reference 10 shows ΔK_r to be $(.09 \times 10^{-4} + .706 \times 10^{-4})$ for air at 100 mm Hg pressure and 290°K when the frequency is 60.156 Gc. The change in cavity resonant frequency is 2.39 Mc when the cavity is filled with air. When a 4-cm oxygen-free wake is in the cavity, the change in resonant frequency is 43 kc less. This figure is rather small when one considers that the linewidth of a $Q = 10^5$ ($L = 25 \text{ cm}$) cavity is 600 kc. The cavity linewidth may be decreased by making the cavity longer (higher Q), but Δf due to the wake also decreases in proportion. Unless some way is found to exploit the very rapid change in ΔK with frequency, it does not appear possible to use the 60 Gc or the 118.75 Gc oxygen lines for diagnostic purposes.

We now turn our attention to the possibility of detecting the presence of nitric oxide by observing the effect of the band of lines around 150 Gc on a Fabry-Perot cavity. Table 1 of Reference 11 shows the absorption and linewidth of pure nitric oxide at temperatures of 80°, 290°, and 1,000°K. The contribution of 1% nitric oxide to the complex dielectric coefficient is shown in Figures 6, 7, and 8

TR65-01D




Figure 1 Effect of 60.433 Gc Oxygen Line on the Q of a Fabry-Perot Cavity. (Cavity Reflection Loss $\approx 10^{-3}$ and 21% Oxygen Molecules in 290°K Air)

TR65-01D

of Reference 11. Figure 2 of the present report shows the effect of a 4-cm $1,000^{\circ}\text{K}$ ($p < 10$ mm Hg) wake on the Q of the Fabry-Perot cavity. The effect is very small. Ten percent of NO in the wake is shown to accentuate the change. The change in resonant Q of the cavity (Equation 4) due to $\Delta K_r = .05 \times 10^{-6}$ (Figure 7a of Reference 11) is also very small, being 600 cps when $d = 4$, $L = 25$, and $f = 150.175$ Gc. The reason Δf is so small is because the lines are much weaker at $T = 1,000^{\circ}\text{K}$ than at low temperatures.

TR65-01D




Figure 2 Effect of 150.1763 Gc Nitric Oxide Line on the Q of a Fabry-Perot Cavity (Cavity Reflection Loss $\approx 10^{-3}$ and 10^{-5} Nitric Oxide Molecules in 1000°K in 4 cm Diameter Wake)

TR65-01D

IV. THE ABSORPTION AND PHASE SHIFT CAUSED BY FREE ELECTRONS

Free electrons as well as neutral gas also have an equivalent complex dielectric coefficient different from unity, giving rise to absorption and phase shift. The power absorption α_ω and phase coefficient of free electrons when the plasma is underdense is given by⁽²¹⁾

$$\alpha_\omega = \frac{\nu}{2c} \left(\frac{\omega_p}{\omega} \right)^2 = \frac{\nu}{2c} \left(\frac{n}{n_c} \right)^2 \quad (5)$$

For a frequency f of 150 Gc, the critical electron density $n_c = 2.94 \times 10^{14} \text{ cm}^{-3}$. The electron collision frequency for heated air is given by⁽²²⁾

$$\nu = \nu_{ea} + \nu_{ei} = 1.8 \times 10^{-8} (T/300)^{1/2} n_a + 6.1 \times 10^{-3} (T/300)^{-3/2} n_i \quad (6)$$

where n_a and n_i are the densities (in cm^{-3}) of neutral particles and ions, respectively, and T is the temperature in $^\circ\text{K}$. If we use the fact that at 290°K there are $3.33 \times 10^{16} p$ molecules per cm^3 (p in mm Hg) and assume that in the heated wake of a high-velocity projectile the particle density is close to ambient, we then obtain, for an electron and ion density of $10^{10}/\text{cm}^3$,

$$\nu = 6.0 \times 10^8 (T/300)^{1/2} p + 6.1 \times 10^7 (T/300)^{-3/2} \quad (7)$$

When the temperature is $1,000^\circ\text{K}$ this equation becomes

$$\nu = 1.09 \times 10^9 p$$

and the attenuation becomes

$$\alpha_\omega = 0.617 \times 10^{-16} n \times p$$

TR65-01D

For $n = 10^{10} \text{ cm}^{-3}$ and $p = 1 \text{ mm Hg}$, $\alpha_{\omega} = 0.617 \times 10^{-6} \text{ cm}^{-1}$. For useful microwave spectroscopy, α_{ω} due to the free electrons must be lower than that for oxygen and nitric oxide. Consequently, the best chance of making useful measurements is when the electron density is low as in the far wake (unfortunately, the concentration of nitric oxide will also be low under these conditions) and at the low pressures. The above value of $\alpha_{\omega} = 0.617 \times 10^{-6} \text{ cm}^{-1}$ for free electrons compares with $\alpha_{\omega} = 2.70 \times 10^{-6} \text{ cm}^{-1}$ (Table 1 of Reference 11) for a concentration of 1% ($n = 3.33 \times 10^{13} \text{ cm}^{-3}$) 1000°K nitric oxide in the flow. We therefore conclude that unless there are many more nitric oxide molecules than electrons in the flow it will not be possible to "see" the nitric oxide.

TR65-01D

V. CONCLUSIONS AND RECOMMENDATIONS

We have examined the possibility of measuring concentrations of molecular oxygen and nitric oxide in the wakes of hypervelocity projectiles by detecting either the absorptive or dispersive behavior of these gases in the microwave region. The instrument under consideration for this purpose is the Fabry-Perot cavity, which can be made very sensitive. Notwithstanding this sensitivity, the possibility is marginal of making useful measurements on the lines considered. There are two reasons for this. The first is that the effect of free electrons may be larger and will swamp the effect of the molecules. The second is that although microwave transitions are easily measurable at low temperature, the intensity of the effects decreases rapidly with increasing temperature. For example, the nitric-oxide transitions decrease by at least a factor of 25 when the temperature is raised from 290°K to 1,000°K.⁽¹¹⁾ In addition, the amount of nitric oxide in wakes is not large and is probably always less than 1%.

Recombination of atomic oxygen into molecular oxygen takes place in the far wake of hypervelocity bodies. It would be very desirable to measure the point at which this happens. The possibility is now examined of doing this by measuring the absorption of molecular oxygen as it forms. It might be just feasible to do this, but the molecular oxygen, which inevitably fills the whole cavity, may mask the effect in the wake. In a shock tube, however, the cavity could be evacuated.

The results of this study suggest that the possibility of using microwave absorption as a plasma diagnostic technique is marginal at present. However, this conclusion is based on very imperfect knowledge and very simple theoretical models. Considerably more information on subjects such as collisional broadening and how it is affected by temperature is required before definite conclusions can be drawn on the feasibility of the method in shock-tube and free-flight range studies.

TR65-01D

Laboratory experiments are suggested as a means to greater understanding of fundamental processes, especially collisional broadening of lines and their temperature dependence.

The high Q's and narrow cavity resonances achievable by submillimeter Fabry-Perot cavities should have considerable application in the determination of spectral line shapes. This subject is of great current interest because of the fundamental information which line shapes can give on such things as interatomic and intermolecular forces and the perturbations they exert on energy levels. As noted previously (Reference 10), the positions and spacings of submillimeter lines give a great deal of information on the forces holding molecules together.

The Fabry-Perot cavity also promises to allow one to measure the anomalous behavior of the real part of the dielectric coefficient around absorption lines. As far as is known, nobody has yet measured both the real (dispersive) and imaginary (absorptive) part of the dielectric coefficient. Such measurements would allow one to check the theories of polarizability.

In conclusion, it is felt that it is very desirable to develop and extend the techniques of submillimeter-wave spectroscopy. Considerable information of basic scientific interest should be generated, and extension of these techniques may lead to useful shock-tube and free-flight range diagnostics.

TR65-01D

VI. REFERENCES

1. A. C. Charters, "The Free Flight Range: A Tool for Research in the Physics of High Speed Flight," Hypersonic Flow Research, F. R. Riddell ed., Academic Press, New York, 1962
2. S. C. Lin, "Survey of Shock Tube Research Related to the Aerophysics Problem of Hypersonic Flight," Hypersonic Flow Research, Academic Press, New York, 1962
3. R. A. Alpher and D. R. White, "Optical Refractivity of High Temperature Gases. I. Effects Resulting from Dissociation of Diatomic Gases," Phys. Fluids 2, March-April 1959, p. 153
4. "Instrumentation, Calibration, and Data Reduction Methods," W. L. Koch ed., GM Defense Research Laboratories Report TR62-213, Dec 1962
5. S. C. Lin and J. E. Hayes, "A Quasi One-Dimensional Model for Chemically Reacting Turbulent Wakes of Hypersonic Objects," AIAA Conference on Physics of Entry into Planetary Atmospheres at MIT, Aug 26 - 28, 1963
6. W. H. Webb and L. A. Hromas, "Mean Electron Levels in the Reacting Turbulent Wake Behind a Sharp Nosed Reentry Body," presented at the 15th AMRAC Meeting, Monterey, California, 17 Apr 1963
7. R. I. Primich and R. A. Hayami, "The Application of the Focused Fabry-Perot Resonator to Plasma Diagnostics," IEEE Trans. on Microwave Theory and Techniques MTT-12, 1964, p. 33
8. D. H. Auston, R. I. Primich and R. A. Hayami, "Further Considerations of the Use of Fabry-Perot Resonators in Microwave Plasma Diagnostics," GM Defense Research Laboratories Report TR64-37, Jun 1964
9. A. Von Hippel, Dielectric and Waves, Wiley and Sons, New York, 1959
10. I. P. French, "A Review of Microwave Absorption and Dispersion of Air Constituents," GM Defense Research Laboratories Report TR65-01A, Jan 1965

TR65-01D

11. I. P. French, "The Microwave Absorption and Dispersion of Heated Air," GM Defense Research Laboratories Report TR65-01C, Jan 1965
12. C. H. Townes and A. L. Schawlow, Microwave Spectroscopy, McGraw-Hill 1955
13. W. Culshaw, "Reflectors for a Fabry-Perot Interferometer," IRE Trans. MTT-8, Mar 1960, p. 182
14. W. Culshaw, "Resonators for Millimeter and Submillimeter Wavelengths," IRE Trans. MTT-9, Mar 1961, p. 135
15. R. W. Zimmerer, et al, "Millimeter Wavelength Resonant Structures," IEEE Trans. MTT-11, Mar 1963, p. 142
16. Y. Beers and G. L. Strine, "Measurement of Voltage by the Use of the Stark Effect," IRE Trans. on Instrumentation, Dec 1962, p. 171
17. J. J. Gallagher, F. D. Bedard and C. M. Johnson, "Microwave Spectrum of $N^{14}O^{16}$," Phys. Rev. 93, No. 4, 1954, p. 729
18. E. H. Young, "The Static and Dynamic Temperature Characteristics of the Oxygen Line at the 2.5 mm Wavelength," U. of Texas, EE. Research Lab Report, No. 7, Jan 1964
19. M. Lichtenstein, J. J. Gallagher and R. E. Cupp, "Millimeter Spectrometer Using a Fabry-Perot Interferometer," Rev. of Sci. Instr. 34, No. 8, Aug 1963, p. 843
20. R. G. Strauch, R. E. Cupp, M. Lichtenstein and J. J. Gallagher, "Quasi-Optical Techniques in Millimeter Spectroscopy," Presented at the Symposium on Quasi-Optics, Polytechnic Institute of Brooklyn, Jun 1964
21. I. P. French, G. G. Cloutier and M. P. Bachynski, "The Absorptivity Spectrum of a Uniform Anisotropic Plasma Slab," Can. J. Phys. 39, Sep 1961, p. 1273
22. J. A. Ratcliffe, The Magneto-Ionic Theory and Its Application to the Ionosphere, Cambridge U. Press, 1959

DISTRIBUTION LIST
for Analysis Reports on the
HYPERVELOCITY RANGE RESEARCH PROGRAM

<u>Recipient</u>	<u>Copy No.</u>	<u>Recipient</u>	<u>Copy No.</u>
Director		U. S. Air Force	
Advanced Research Projects Agency		Ballistic Systems Division	
Washington 25, D. C. 20315		AF Unit Post Office	
ATTN: F. Koether	1 - 3	Los Angeles 45, California	
ATTN: Dr. B. Fisher	4	ATTN: Major R. Fowler/WDTVP	45
ATTN: C. McLain	5	ATTN: Major W. Levy	46
ATTN: Major J. Kiernan	6	ATTN: Lt. K. G. Jefferson	47
Aerojet-General Corporation		Bell Telephone Laboratories	
P. O. Box 296		Murray Hill, New Jersey	
Azusa, California		ATTN: Dr. I. Pelech	48
ATTN: Technical Library	7	ATTN: Dr. S. P. Morgan	49
Aeronutronics Division, Ford Motor Co.		ATTN: Dr. S. J. Buschsbaum	50
Ford Road		USAF Cambridge Research Laboratories	
Newport Beach, California		Laurence Hanscom Field	
ATTN: L. H. Linder, Manager Technical		Bedford, Massachusetts	
Information Services	8	ATTN: CRRELRL, Stop 29	51
Aerospace Corporation		Director	
2400 E. El Segundo Blvd.		USAF Office of Scientific Research	
El Segundo, California		Washington 25, D. C.	
ATTN: Manager of Penetration Aids	9	ATTN: Mechanics Division/ Major Terrell	52
Aerospace Corporation		Director	
P. O. Box 95085		Ames Research Center	
Los Angeles 45, California		Moffett Field, California	
ATTN: J. Logan	10	ATTN: H. Allen	53
Aerospace Corporation		Applied Physics Laboratory	
San Bernardino, California		The Johns Hopkins University	
ATTN: Mr. R. Fowler	11	8621 Georgia Avenue	
ATTN: Mr. Howard Myers	12 - 41	Silver Spring, Maryland	
Avco-Everett Research Laboratory		ATTN: G. Seielstad	54
2385 Revere Beach Parkway		Research and Advanced Development Division	
Everett 49, Massachusetts		Avco Corporation,	
ATTN: Dr. Bennet Kivel	42	201 Lowell St	
ATTN: Technical Library	43	Wilmington, Massachusetts	
Applied Physics Laboratory		ATTN: Dr. A. Pallone	55
Sylvania Elec. Products		ATTN: Dr. W. E. Gibson	56
Waltham, Massachusetts		ATTN: Dr. J. Ekerman	57
ATTN: R. Row	44	ATTN: Dr. Wentink	58
		ATTN: Dr. H. DeBolt	59
		ATTN: H. Bell	60
		ATTN: Technical Library	61

DISTRIBUTION LIST (CONT'd)

<u>Recipient</u>	<u>Copy No.</u>	<u>Recipient</u>	<u>Copy No.</u>
Commanding General U. S. Army Air Defense Command Colorado Springs, Colorado ATTN: Advanced Projects Division, G-3	52	U. S. Army Technical Intelligence Agency Arlington Hall Station Arlington 12, Virginia ATTN: ORDLI	80
Commanding General U. S. Army Ballistics Research Laboratories Aberdeen Proving Ground, Maryland ATTN: C. H. Murphy	63	ARO, Inc. von Karman Facility Tullahoma, Tennessee ATTN: J. Lukaszewicz	81
ATTN: B. J. Karpov	64	Air Force Ballistic Systems Division Norton Air Force Base, California 92409 ATTN: Major Thurmond Deloney -	
Commanding General U. S. Army Elec. and Communications Command Research and Development Fort Monmouth, New Jersey	65	BSYST	82
Commanding General U. S. Army Materiel Command Washington 25, D. C.	66	Special Projects Office Department of the Navy Washington 25, D. C. ATTN: Martin Bloom/SP-272	83
Commanding General U. S. Army Missile Command Redstone Arsenal, Alabama 35809 ATTN: AMSMI-RB	67	Barnes Engineering Company 30 Commerce Road Stamford, Connecticut ATTN: H. Yates	84
ATTN: AMSMI-RRX	68	Battelle Memorial Institute 505 King Avenue Columbus 1, Ohio ATTN: Battelle-DEFENDER	85
ATTN: AMSMI-RNR	69 - 73	Bell Telephone Laboratories, Inc. Whippany, New Jersey ATTN: C. W. Hoover, Room 2B-105	86
NIKE X Project Manager U. S. Army Materiel Command Redstone Arsenal, Alabama ATTN: AMCPM-ZER-R	74	ATTN: N. H. Brown	87
ATTN: AMCPM-ZER-RB	75	ATTN: John McCarthy	88
Commanding General U. S. Army Research and Development Washington 25, D. C. ATTN: Intl. Division	76	Bendix Corporation Systems Division 3300 Plymouth Road Ann Arbor, Michigan ATTN: Systems Analysis and Math Dept.	89
ATTN: Physical Sciences Division	77	ATTN: Flight Sciences Department	90
Commanding Officer U. S. Army Signal Missile Support Agency White Sands Missile Range, New Mexico ATTN: SIGWS-MM-1	78	Boeing Airplane Company P. O. Box 3707 Seattle, Washington ATTN: Org. 2-5732/J. Klaimon	91
ATTN: MEW	79	Brown Engineering Company Huntsville, Alabama ATTN: Technical Library	92

DISTRIBUTION LIST (CONT'd)

<u>Recipient</u>	<u>Copy No.</u>	<u>Recipient</u>	<u>Copy No.</u>
California Institute of Technology Pasadena, California ATTN: Prof. L. Lees	93	General Electric Company, MSVD MSD Re-entry Physics Library Unit 3198 Chestnut Street Philadelphia, Pennsylvania ATTN: L. I. Chasen, Room 3446	108
Central Intelligence Agency 2930 E Street, N. W. Washington D. C. ATTN: OCR Standard Distribution	94-96	ATTN: Manager - MSVD Library, Room 3446	109
Communication and Propagation Laboratory Stanford Research Institute Menlo Park, California ATTN: Mr. Ray L. Leadabrand, Head, Propagation Group	97	Geophysics Corporation of America Burlington Road Bedford, Massachusetts	110
ATTN: Dr. Carson Flammer	98	Heliodyne Corporation 2365 Westwood Blvd. Los Angeles 64, California ATTN: S. Feldman	111
University of Michigan Willow Run Laboratories P.O. Box 2008, Ann Arbor, Michigan ATTN: BAMIRAC/B. R. George	99	Institute for Defense Analyses 400 Army-Navy Drive Arlington, Virginia 22202 ATTN: Dr. J. Menkes	112
Cornell Aeronautical Laboratory 4455 Genesee Street Buffalo 21, New York ATTN: J. Lotsof	100	ATTN: Dr. L. Biberman	113
ATTN: W. Wurster	101	ATTN: Dr. R. Fox	114
ATTN: Applied Physics Dept.	102	ATTN: Dr. J. Martin	115
Defense Research Corporation 6300 Hollister Avenue, Goleta, California ATTN: W. Short	103	ATTN: Mr. D. Katcher, JASON Library	116
Director Electromagnetic Warfare Laboratory Wright-Patterson Air Force Base Dayton, Ohio ATTN: ASRN/W. Bahret	104	ATTN: Mr. H. Wolfhard	117
Electro-Optical Systems, Inc. 300 N. Halstead Street Pasadena, California ATTN: R. Denison	105	Polytechnic Institute of Brooklyn 333 Jay Street Brooklyn, New York ATTN: Dr. N. Marcuvitz	118
General Applied Sciences Laboratories Merrick and Steward Avenues Westbury, Long Island, New York ATTN: R. Byrne	106	Jet Propulsion Laboratory 4800 Oak Grove Drive Pasadena, California ATTN: H. Denslow	119
General Dynamics Corporation Astronautics Division, P.O. Box 1128 San Diego, California 92112 ATTN: Library and Information Services (128-00)	107	ATTN: Library	120
		Kaman Nuclear Division Colorado Springs, Colorado ATTN: A. Bridges	121
		Director, Langley Research Center Langley Field, Virginia ATTN: W. Erickson	122
		ATTN: R. L. Trimpi	123
		Lockheed Corporation Missiles and Space Division Sunnyvale, California ATTN: Ray Munson	124
		Special Projects Office Bureau of Weapons Munitions Building, Washington, D. C. ATTN: Cdr. Julian SP-25	125

DISTRIBUTION LIST (CONT'd)

<u>Recipient</u>	<u>Copy No.</u>	<u>Recipient</u>	<u>Copy No.</u>
Martin Aircraft Company Orlando, Florida ATTN: J. Mays	126	Purdue University School Aero and Engineering Sciences LaFayette, Indiana ATTN: I. Kvakovsky	139
Director Marshall Space Flight Center Huntsville, Alabama ATTN: M-AER-TS	127	Radio Corporation of America Missiles and Surface Radar Division Moorestown, New Jersey	140
Massachusetts Institute of Technology Lincoln Laboratory P. O. Box 73 Lexington 73, Massachusetts ATTN: M. Herlin	128	The Rand Corporation 1700 Main Street Santa Monica, California ATTN: Library	141
ATTN: R. Slattery	129	Raytheon Manufacturing Company Missile Systems Division Bedford, Massachusetts	
ATTN: V. Guethlen	130	ATTN: I. Britton, Librarian	142
Chief U. S. Navy Bureau of Weapons Washington 25, D. C. ATTN: RMWC-322	131	Rome Air Development Center Griffiss Air Force Base Rome, New York ATTN: P. Sandler	143
Chief of Naval Operations Washington 25, D. C. ATTN: OP-07T10	132	The Martin Company Aerospace Division, Mail No. T-38 P.O. Box 179, Denver, Colorado 80201 ATTN: R. E. Compton, Jr.	144
Commander U. S. Naval Ordnance Laboratory White Oak, Silver Springs, Maryland ATTN: Technical Library	133	Space Technology Laboratories, Inc. 1 Space Park Redondo Beach, California ATTN: Leslie Hromas	145
Director U. S. Naval Research Laboratory Washington 25, D. C. ATTN: Code 2027	134	The Warner and Swasey Company Control Instrument Division 32-16 Downing Street Flushing 54, New York	146
New York University Department of Aero Engineering University Heights New York 53, New York ATTN: L. Arnold	135	University of California San Diego, California ATTN: Prof. N. M. Kroll	147
North American Aviation Space and Information Systems Division 12214 Lakewood Blvd. Downey, California ATTN: E. Allen	136	University of California Lawrence Radiation Laboratory Livermore, California ATTN: C. Craig	148
Princeton University Princeton, New Jersey ATTN: Prof. E. Frieman	137	National Aeronautics and Space Administration Science and Technical Information Division (SAK/DL)	
ATTN: Prof. S. Bogdonoff	138	P.O. Box 5700, Bethesda, Maryland 20014 ATTN: NASA Representative (SAK/DL-639)	149, 150
		ATTN: Head, Operations Section	151, 152

DISTRIBUTION LIST (CONT'd)

<u>Recipient</u>	<u>Copy No.</u>	<u>Recipient</u>	<u>Copy No.</u>
General Electric Company Re-entry Systems Department Missile and Space Division P. O. Box 8555 Philadelphia, Pennsylvania ATTN: Mr. H. W. Ridyard	153	Defense Documentation Center Cameron Station Alexandria, Virginia	161 - 180
University of Michigan Radiation Laboratory 201 Catherine Ann Arbor, Michigan ATTN: R. J. Leite	154	Armour Research Foundation 10 W. 35th Street Chicago 16, Illinois ATTN: Fluid Dynamics Research Division	181
Valley Forge Space Technical Center General Electric Company P. O. Box 8555 Philadelphia 1, Pennsylvania ATTN: J. Farber	155	Lincoln Laboratory 244 Wood Street Lexington 73, Massachusetts 02173 ATTN: Dr. S. Edelberg	182
Director Weapons Systems Evaluation Group Pentagon, Room 1E-800 Washington 25, D. C. 20315	156	Institute of Science and Technology The University of Michigan P. O. Box 618 ATTN: BAMIRAC Library	183
U. S. Army Liaison Office Canadian Armament Research and Development Establishment P. O. Box 1427 Quebec, P. Q., Canada ATTN: Lt. Col. E. W. Kreischer	157	HQ BSD (AFSC) AF Unit Post Office Los Angeles 45, California ATTN: BSRVD	184
*Commanding General U. S. Army Missile Command Redstone Arsenal, Alabama 35809 ATTN: SMIDW-BI(C)	158	Commanding Officer Kwajalein Test Site APO 555, Box 26 San Francisco, California	185
United Aircraft Corporation Research Laboratories East Hartford, Connecticut ATTN: Dr. R. Meyerand	159	Capt. L. L. Schoen, USAF USAF Technical Representative c/o GM Defense Research Laboratories	186
Monsanto Research Corporation Boston Laboratory Everett, Massachusetts 02149 ATTN: Dr. L. Gilman	160	GM Defense Research Laboratories	187 and above

* Unclassified reports only.

GM Defense Research Laboratories, General Motors Corp., Santa Barbara, California

THE DIAGNOSTIC APPLICATIONS OF MICROWAVE ABSORPTION AND DISPERSION by I. P. French, TR65-01D, January 1965. 15 pp. inc. illus., 22 refs.

Unclassified Report

The possibility of measuring species concentration in high-temperature air by microwave spectroscopy is considered. The species selected for consideration are molecular oxygen, which has transitions in the region from 52 to 68 Gc, and nitric oxide with transitions around 150 Gc. The feasibility appears marginal, but this evaluation is based on many approximations and assumptions and further work is required for definitive conclusions.

- (Unclassified)
1. Microwaves - Absorption
 2. Microwaves - Dispersion
 3. Microwaves - Propagation
 4. Microwaves - Polarization
 5. Microwaves - Temperature factors
 6. Dielectrics - Properties
 - I. DA-01-021-AMC-11359(Z)
 - II. TR65-01D
 - III. French, I. P.

GM Defense Research Laboratories, General Motors Corp., Santa Barbara, California

THE DIAGNOSTIC APPLICATIONS OF MICROWAVE ABSORPTION AND DISPERSION by I. P. French, TR65-01D, January 1965. 15 pp. inc. illus., 22 refs.

Unclassified Report

The possibility of measuring species concentration in high-temperature air by microwave spectroscopy is considered. The species selected for consideration are molecular oxygen, which has transitions in the region from 52 to 68 Gc, and nitric oxide with transitions around 150 Gc. The feasibility appears marginal, but this evaluation is based on many approximations and assumptions and further work is required for definitive conclusions.

- (Unclassified)
1. Microwaves - Absorption
 2. Microwaves - Dispersion
 3. Microwaves - Propagation
 4. Microwaves - Polarization
 5. Microwaves - Temperature factors
 6. Dielectrics - Properties
 - I. DA-01-021-AMC-11359(Z)
 - II. TR65-01D
 - III. French, I. P.

GM Defense Research Laboratories, General Motors Corp., Santa Barbara, California

THE DIAGNOSTIC APPLICATIONS OF MICROWAVE ABSORPTION AND DISPERSION by I. P. French, TR65-01D, January 1965. 15 pp. inc. illus., 22 refs.

Unclassified Report

The possibility of measuring species concentration in high-temperature air by microwave spectroscopy is considered. The species selected for consideration are molecular oxygen, which has transitions in the region from 52 to 68 Gc, and nitric oxide with transitions around 150 Gc. The feasibility appears marginal, but this evaluation is based on many approximations and assumptions and further work is required for definitive conclusions.

- (Unclassified)
1. Microwaves - Absorption
 2. Microwaves - Dispersion
 3. Microwaves - Propagation
 4. Microwaves - Polarization
 5. Microwaves - Temperature factors
 6. Dielectrics - Properties
 - I. DA-01-021-AMC-11359(Z)
 - II. TR65-01D
 - III. French, I. P.

GM Defense Research Laboratories, General Motors Corp., Santa Barbara, California

THE DIAGNOSTIC APPLICATIONS OF MICROWAVE ABSORPTION AND DISPERSION by I. P. French, TR65-01D, January 1965. 15 pp. inc. illus., 22 refs.

Unclassified Report

The possibility of measuring species concentration in high-temperature air by microwave spectroscopy is considered. The species selected for consideration are molecular oxygen, which has transitions in the region from 52 to 68 Gc, and nitric oxide with transitions around 150 Gc. The feasibility appears marginal, but this evaluation is based on many approximations and assumptions and further work is required for definitive conclusions.

- (Unclassified)
1. Microwaves - Absorption
 2. Microwaves - Dispersion
 3. Microwaves - Propagation
 4. Microwaves - Polarization
 5. Microwaves - Temperature factors
 6. Dielectrics - Properties
 - I. DA-01-021-AMC-11359(Z)
 - II. TR65-01D
 - III. French, I. P.

(Descriptors) Micro-
waves, Spectroscopy, Gas
analysis, Dielectric
properties, Absorption
Propagation, Dispersion,
Air, Oxygen, Nitric
oxide, Polarization

(Descriptors) Micro-
waves, Spectroscopy, Gas
analysis, Dielectric
properties, Absorption
Propagation, Dispersion,
Air, Oxygen, Nitric
oxide, Polarization

(Descriptors) Micro-
waves, Spectroscopy, Gas
analysis, Dielectric
properties, Absorption
Propagation, Dispersion,
Air, Oxygen, Nitric
oxide, Polarization

(Descriptors) Micro-
waves, Spectroscopy, Gas
analysis, Dielectric
properties, Absorption
Propagation, Dispersion,
Air, Oxygen, Nitric
oxide, Polarization

GM Defense Research Laboratories, General Motors Corp. . Santa Barbara, California

THE DIAGNOSTIC APPLICATIONS OF MICROWAVE ABSORPTION AND DISPERSION by I. P. French, TR65-01D, January 1965. 15 pp. inc. illus., 22 refs.

Unclassified Report

The possibility of measuring species concentration in high-temperature air by microwave spectroscopy is considered. The species selected for consideration are molecular oxygen, which has transitions in the region from 52 to 68 Gc, and nitric oxide with transitions around 150 Gc. The feasibility appears marginal, but this evaluation is based on many approximations and assumptions and further work is required for definitive conclusions.

- (Unclassified)
1. Microwaves - Absorption
 2. Microwaves - Dispersion
 3. Microwaves - Propagation
 4. Microwaves - Polarization
 5. Microwaves - Temperature factors
 6. Dielectrics - Properties
 - I. DA-01-021-AMC-11359(Z)
 - II. TR65-01D
 - III. French, I. P.

GM Defense Research Laboratories, General Motors Corp. . Santa Barbara, California

THE DIAGNOSTIC APPLICATIONS OF MICROWAVE ABSORPTION AND DISPERSION by I. P. French, TR65-01D, January 1965. 15 pp. inc. illus., 22 refs.

Unclassified Report

The possibility of measuring species concentration in high-temperature air by microwave spectroscopy is considered. The species selected for consideration are molecular oxygen, which has transitions in the region from 52 to 68 Gc, and nitric oxide with transitions around 150 Gc. The feasibility appears marginal, but this evaluation is based on many approximations and assumptions and further work is required for definitive conclusions.

- (Unclassified)
1. Microwaves - Absorption
 2. Microwaves - Dispersion
 3. Microwaves - Propagation
 4. Microwaves - Polarization
 5. Microwaves - Temperature factors
 6. Dielectrics - Properties
 - I. DA-01-021-AMC-11359(Z)
 - II. TR65-01D
 - III. French, I. P.

GM Defense Research Laboratories, General Motors Corp. . Santa Barbara, California

THE DIAGNOSTIC APPLICATIONS OF MICROWAVE ABSORPTION AND DISPERSION by I. P. French, TR65-01D, January 1965. 15 pp. inc. illus., 22 refs.

Unclassified Report

The possibility of measuring species concentration in high-temperature air by microwave spectroscopy is considered. The species selected for consideration are molecular oxygen, which has transitions in the region from 52 to 68 Gc, and nitric oxide with transitions around 150 Gc. The feasibility appears marginal, but this evaluation is based on many approximations and assumptions and further work is required for definitive conclusions.

- (Unclassified)
1. Microwaves - Absorption
 2. Microwaves - Dispersion
 3. Microwaves - Propagation
 4. Microwaves - Polarization
 5. Microwaves - Temperature factors
 6. Dielectrics - Properties
 - I. DA-01-021-AMC-11359(Z)
 - II. TR65-01D
 - III. French, I. P.

GM Defense Research Laboratories, General Motors Corp. . Santa Barbara, California

THE DIAGNOSTIC APPLICATIONS OF MICROWAVE ABSORPTION AND DISPERSION by I. P. French, TR65-01D, January 1965. 15 pp. inc. illus., 22 refs.

Unclassified Report

The possibility of measuring species concentration in high-temperature air by microwave spectroscopy is considered. The species selected for consideration are molecular oxygen, which has transitions in the region from 52 to 68 Gc, and nitric oxide with transitions around 150 Gc. The feasibility appears marginal, but this evaluation is based on many approximations and assumptions and further work is required for definitive conclusions.

- (Unclassified)
1. Microwaves - Absorption
 2. Microwaves - Dispersion
 3. Microwaves - Propagation
 4. Microwaves - Polarization
 5. Microwaves - Temperature factors
 6. Dielectrics - Properties
 - I. DA-01-021-AMC-11359(Z)
 - II. TR65-01D
 - III. French, I. P.

(Descriptors) Micro-
waves, Spectroscopy, Gas
analysis, Dielectric
properties, Absorption
Propagation, Dispersion,
Air, Oxygen, Nitric
oxide, Polarization

(Descriptors) Micro-
waves, Spectroscopy, Gas
analysis, Dielectric
properties, Absorption
Propagation, Dispersion,
Air, Oxygen, Nitric
oxide, Polarization

(Descriptors) Micro-
waves, Spectroscopy, Gas
analysis, Dielectric
properties, Absorption
Propagation, Dispersion,
Air, Oxygen, Nitric
oxide, Polarization

(Descriptors) Micro-
waves, Spectroscopy, Gas
analysis, Dielectric
properties, Absorption
Propagation, Dispersion,
Air, Oxygen, Nitric
oxide, Polarization

UNCLASSIFIED

UNCLASSIFIED